




CENTER DIFF EXPLODED VIEW

The diagram illustrates the exploded view of the center differential assembly. Key components and their part numbers are labeled as follows:

- ARA310991 ASSEMBLED CENTER DIFF**: The main assembled unit.
- ARA310978**: A large gear component.
- ARA310982**: A small circular plate or washer.
- ARA311094**: Small spacers or washers.
- ARA716033**: A larger circular plate or washer.
- ARA310985**: A small pin or clip.
- ARA310984**: Multiple small gears or shims.
- ARA713033**: A central shaft or pin.
- ARA610037**: A bearing or bushing.
- ARA311187**: A bolt or screw.
- AR722312**: A long pin or axle component.

A detailed inset box titled "Limited Slip Effect" shows two configurations of the internal gear set:

- MAXIMUM effect**: Shows three faces of the gear set engaged, labeled "3x faces".
- MINIMUM effect**: Shows one face of the gear set engaged, labeled "1x face".

FRONT & REAR DIFF EXPLODED VIEW

ARA311187

ARA310983

ARA610037

ARA311094

ARA716033

ARA310984

ARA310985

ARA311094

ARA713033

ARA310982

ARA722312

ARA610037

ARA310980

ARA311187

ARA310984

ARA311199

TECHNICAL PACK!
TECHNISCHES PACK!
PACK TECHNIQUE!

EXPLODED VIEW EXPLOSIONSANSICHT VUE ÉCLATÉE

EXPLODED VIEW EXPLOSIONSANSICHT VUE ÉCLATÉE

SHOCK ABSORBER EXPLODED VIEW

The image displays two exploded view diagrams of shock absorbers, labeled 'FRONT' and 'REAR'. Each diagram shows the main shock absorber body and its associated components, including mounting hardware, springs, and dust boots. The parts are identified by alphanumeric codes.

FRONT

ARA-1510

ARA330811

ARA330812

ARA330813

AR715008

AR330339

AR709051

AR330479

AR716010

AR330514

ARA330776

ARA330780

AR330245

AR330339

AR330245

AR330339

AR330513

ARA330786

ARA330608

ARA330814

REAR

ARA-1511

ARA330811

ARA330812

ARA330813

AR715008

AR330339

AR709051

AR330481

AR716010

AR330514

ARA330777

ARA330782

AR330245

AR330339

AR330245

AR330339

AR330513

ARA330788

ARA330608

ARA330814