











HOW TO... WIE... COMMENT...

Change the Pinion / Motor. Wechseln Sie das Motorzahnrad / Motor. Changez le Pignon / Moteur.

OPTIONS....OPTIONEN.... POSSIBILITÉS....



ARA311156 - Metal Gear F/R Transmission Module Set (37T/13T, 1.35M)



ARA340191 - Aluminum Steering Rack



- ARA310996 - 13T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA310997 - 14T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA310998 - 15T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA310999 - 16T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311000 - 17T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311001 - 18T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311002 - 19T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311003 - 20T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311004 - 21T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311005 - 22T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311006 - 23T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311007 - 24T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311008 - 25T 0.8 Mod Safe-D5 CNC Steel Pinion Gear
- ARA311009 - 26T 0.8 Mod Safe-D5 CNC Steel Pinion Gear

