





QUICKSTART GUIDE




1. Remove the Body




5. Install the Transmitter Batteries




2. Remove the Vehicle Battery




6. Power On the Transmitter




3. Charge the Vehicle Battery




7. Power On the Vehicle






4. Reinstall the Vehicle Battery





8. Reinstall the Body




9. Throttle/Brake




10. Steering




11. Throttle Limiter




12. Steering Rate




13. Steering Trim




14. Remove the Body



16. Disconnect the Vehicle Battery



15. Power Off the Vehicle



17. Power Off the Transmitter

