

#VALUE!

Athearn HO 2-6-0 Mogul Locomotive

Sound Decoder Function Assignments <small>2025 Production Run</small>			
Function Key	Default Effect	Function Key	Default Effect
F0	Headlight/Backup Light	F11	Brake Set/Release ³
F1	Bell	F12	Blow Down
F2	Whistle	F13	Couple/Uncouple
F3	Short Whistle ¹	F14	Half Speed & Momentum Override
F4	Cylinder Cocks	F15	Grade Crossing
F5	Lighting Effect 1 ²	F16	Water Stop
F6	Lighting Effect 1 ²	F23	Conductor Whistle/Coach Doors
F7	Dimmer	F24	(Not Used)
F8	Mute	F25	(Not Used)
F9	Drift On	F28	(Not Used)
F10	Drift Off	Emergency Stop	Emergency Stop

1 - The short horn function can be changed to a grade crossing horn sequence by changing CV 37 to 0. If you would like to re-map the short horn function to another key using SoundTraxx's Flex-Map function mapping, CV 37 must also be set to 0 to prevent the short horn function from being activated with function key 3.

2 - If equipped

3 - Functional braking is not enabled by default