



#### **NOTICE**

All instructions, warranties and other collateral documents are subject to change at the sole discretion of Horizon Hobby, LLC. For up-to-date product literature, visit horizonhobby.com or towerhobbies.com and click on the support or resources tab for this product.

#### **MEANING OF SPECIAL LANGUAGE**

The following terms are used throughout the product literature to indicate various levels of potential harm when operating this product:

**WARNING:** Procedures, which if not properly followed, create the probability of property damage, collateral damage, and serious injury OR create a high probability of superficial injury.

**CAUTION:** Procedures, which if not properly followed, create the probability of physical property damage AND a possibility of serious injury.

**NOTICE:** Procedures, which if not properly followed, create a possibility of physical property damage AND a little or no possibility of injury.

**WARNING:** Read the ENTIRE instruction manual to become familiar with the features of the product before operating. Failure to operate the product correctly can result in damage to the product, personal property and cause serious injury.

This is a sophisticated hobby product. It must be operated with caution and common sense and requires some basic mechanical ability. Failure to operate this Product in a safe and responsible manner could result in injury or damage to the product or other property. This product is not intended for use by children without direct adult supervision. Do not use with incompatible components or alter this product in any way outside of the instructions provided by Horizon Hobby, LLC. This manual contains instructions for safety, operation and maintenance. It is essential to read and follow all the instructions and warnings in the manual, prior to assembly, setup or use, in order to operate correctly and avoid damage or serious injury.

Age Recommendation: Not for children under 14 years. This is not a toy.

## **SAFETY PRECAUTIONS AND WARNINGS**

As the user of this product, you are solely responsible for operating in a manner that does not endanger yourself and others or result in damage to the product or property of others.

This model is controlled by a radio signal subject to interference from many sources outside your control. This interference can cause momentary loss of control, so it is advisable to always keep a safe distance in all directions around your model as this margin will help avoid collisions or injury.

- · Never operate your model with low transmitter batteries.
- Always operate your model in open spaces away from full-size vehicles, traffic and people.
- Never operate the model in the street or in populated areas for any reason.
- Carefully follow the directions and warnings for this and any optional support equipment (chargers, rechargeable battery packs, etc.) you use.
- Keep all chemicals, small parts and anything electrical out of the reach of children.
- Never lick or place any portion of the model in your mouth as it could cause serious injury or even death.
- Exercise caution when using tools and sharp instruments.
- Take care during maintenance as some parts may have sharp edges.
- Immediately after using your model, do NOT touch equipment such as the motor, electronic speed control and battery, because they generate high temperatures. You may burn yourself seriously touching them.
- Do not put fingers or any objects inside rotating and moving parts, as this may cause damage or serious injury.
- Always turn on your transmitter before you turn on the receiver in the car. Always turn off the receiver before turning your transmitter off.
- Keep the wheels of the model off the ground when checking the operation of the radio equipment.



TABLE OF CONTENTS			
Charge the Vehicle Battery	4	Binding the Transmitter and Receiver	9
Transmitter Layout		Button Functions	10
Install the Transmitter Batteries	6	Receiver and ESC Wiring Diagram	11
Remove the Vehicle Body	6	Parts List	11
Install the Vehicle Battery		Troubleshooting	12
Power On the Transmitter		Limited Warranty	12
Install the Body	8	Warranty and Service Contact Information	
Power On the Vehicle		FCC Information	
Test the Controls	8	IC Information	15
Steering Trim	9	Compliance Information for the European Union	115
After Driving		Exploded Views	

## **BOX CONTENTS**

INCLUDED COMPONENTS			
Vehicle Axial® SCX30 1/30 Scale 4X4 Rock Crawler RTR			
Transmitter	SLT2 2-CH 2.4GHz (SPMRSLT270)		
Charger	Axial USB 2S Charger: 0.5A JST-XH 3P (not sold separately)		
Vehicle Battery	Spektrum™ 7.4V 160mAh 2S Li-Po: PH (SPMX-1122)		
Motor	Varies between chassis, see slip sheet		
ESC/Receiver	Spektrum™ SCX30 SLT Brushed 2-in-1 ESC / Receiver Combo (SPMXSE3225RX)		
Servo	SX112 Servo: SCX30 (SPMSSX112)		
Transmitter Batteries	(4) AA Alkaline		

### **USB CHARGING WARNINGS**

**WARNING:** Failure to exercise caution while using this product and comply with the following warnings could result in product malfunction, electrical issues, excessive heat, FIRE, and ultimately injury and property damage.

- NEVER LEAVE CHARGING BATTERIES UNATTENDED.
- NEVER CHARGE BATTERIES OVERNIGHT.
- Never attempt to charge dead, damaged or wet battery packs.
- Never attempt to charge a battery pack containing different types of batteries.
- Never allow children under 14 years of age to charge battery packs.
- Never charge batteries in extremely hot or cold places or place in direct sunlight.
- Never charge a battery if the cable has been pinched or shorted.
- Never connect the charger if the power cable has been pinched or shorted.
- Never attempt to dismantle the charger or use a damaged charger.
- Always use only rechargeable batteries designed for use with this type of charger.
- Always inspect the battery before charging.
- · Always keep the battery away from any material that could be affected by heat.
- · Always monitor the charging area and have a fire extinguisher available at all times.
- Always end the charging process if the battery becomes hot to the touch or starts to change form (swell) during the charge process.
- Always connect the positive leads (+) and negative leads (-) correctly.

#### EN

- · Always disconnect the battery after charging, and let the charger cool between charges.
- · Always charge in a well-ventilated area.
- Always terminate all processes and contact Horizon Hobby if the product malfunctions.
- Charge only rechargeable batteries. Charging non-rechargeable batteries may cause the batteries to burst, resulting in injury to persons and/or damage to property.
- The USB outlet shall be installed near the equipment and shall be easily accessible.

**CAUTION:** Always ensure the battery you are charging meets the specifications of this charger. Not doing so can result in excessive heat and other related product malfunctions, which can lead to user injury or property damage. Please contact Horizon Hobby or an authorized retailer with compatibility questions.

**CAUTION:** If at any time during the charge process the battery pack becomes hot or begins to puff, disconnect the battery immediately and discontinue the charge process as batteries can cause fire, collateral damage and injuries.

### **CHARGE THE VEHICLE BATTERY**

Refer to the charging warnings before attempting to charge the battery. Your vehicle comes with a 2S 7.4V USB-C Li-Po battery charger and 2S 7.4V 160mAh Li-Po battery.

CHARGER SPECIFICATIONS			
Input Voltage	5V		
Input Current	1A		
Output Charging Current	0.5A		

- 1. Insert the charger into a computer USB port or a USB power supply, such as those used to charge cellular phones.
  - Always confirm the output voltage of your USB power supply conforms to the charger specifications above before attempting to connect the charger.
- 2. Connect the battery balance connector to the charge port of the battery charger.

#### LED INDICATIONS

When you make the connection successfully, the LEDs on the charger glows solid red and blinking green, indicating charging has begun.

Charging a fully discharged (not over-discharged) 160mAh battery takes approximately 20–40 minutes. The LED glows solid green when the charge is complete.

Red Solid and Green Blinking LED: Charging Red and Green Solid LED: Charging Complete Red Solid LED: Power Connected (Stand By) Red Blinking LED Only: Battery Error Red and Green Blinking LED: Charger Error Red Blinking and Green Solid LED: Input (V) too high


CAUTION: Once charging is complete, immediately remove the battery. Never leave a battery connected to the charger.



### TRANSMITTER LAYOUT

Use the diagram below to familiarize yourself with the different parts of your transmitter.


The transmitter antenna is mounted internally and is located in the front portion of the transmitter. When you are driving your model, hold the transmitter so it is oriented as close to vertical as possible. Do not try to follow your model with the transmitter. This provides the best RF signal between the transmitter and the receiver. Do not cover the front of the transmitter during use as doing so can block the RF signal, resulting in long of central.




## **INSTALL THE TRANSMITTER BATTERIES**


- 1. Press the battery compartment latch and rotate the batter cover to open.
- 2. Install 4 AA alkaline batteries, verifying correct polarity.
- 3. Close the battery cover until it latches.

**CAUTION:** NEVER remove the transmitter batteries while the vehicle is powered ON. Loss of vehicle control, damage, or injury may occur.




## **REMOVE THE VEHICLE BODY**







## **INSTALL THE VEHICLE BATTERY**




## **POWER ON THE TRANSMITTER**



## **INSTALL THE BODY**



## **POWER ON THE VEHICLE**





## **TEST THE CONTROLS**


With the vehicle wheels off the ground, test the throttle and steering controls. Ensure the wheels spin in the proper direction and the front wheels turn in the proper direction with steering input.


After checking for proper direction of controls, start driving slowly. If the vehicle does not go straight without steering input, adjust the steering trim dial on the transmitter until the vehicle holds a straight line with no steering input.

Have FUN driving your vehicle!











### STEERING TRIM



## **AFTER DRIVING**

When you are finished driving your vehicle:


 Press and hold for 1 second, then release to power off vehicle.



2. Press and hold for 1 second, then release to power off the transmitter.



 Remove the vehicle battery and charge if necessary.
 Gently unplug the battery plug by holding the wire close to the plug and carefully pulling straight up.



## **BINDING THE TRANSMITTER AND RECEIVER**

Binding is the process of programming the receiver to recognize a specific transmitter signal, thus preventing interference from other transmitters. The transmitter and receiver included with your vehicle are bound at the factory. If you need to rebind, follow the instructions below.

**NOTICE:** Do not attempt to bind the transmitter and receiver if any other compatible transmitters are in bind mode within approximately 400 feet (120 meters). Doing so may result in unexpected binding to the wrong transmitter and loss of control of your vehicle.

Prior to starting the binding procedure, ensure the servos and motor are connected to the proper ports on the receiver and the transmitter has fresh batteries installed.

- 1. Connect the battery to the receiver.
- 2. Press and hold the power button for 3 seconds. The red light flashes rapidly.
- 3. Release the button. The receiver is in bind mode.
- 4. Power ON the transmitter.
- 5. When the 2-in-1 and transmitter LEDs glows solid, binding is complete.

The receiver LED will glow solid when both the transmitter and receiver are powered on. If the receiver LED flashes rapidly or is not illuminated, the transmitter and receiver are not bound. Power off both the transmitter and receiver and repeat the binding procedure.

## **BUTTON FUNCTIONS**

POWER ON/OFF: ON: Press and hold for 1 second. OFF: Press and hold for 1 second.

**IMPORTANT:** Do not leave the battery connected after use. Even when powered OFF there is a small current drain which will damage the battery.

#### PROGRAMMABLE SETTINGS

Use the power button to select programmable settings. Power the vehicle ON to begin programming the settings. The LED indicates the selection.

#### **Running Mode Setting**

There are four Running Modes.

- 1. Press and hold the power button for three seconds. The LED slowly flashes once.
- 2. Release the power button. The number of flashes indicates the Running Mode Setting.
- 3. Press the power button to move to the next option.
  - F/R with 100% Reverse Speed = Default setting
  - F/B/R with 100% Reverse Speed
  - F/R with 50% Reverse Speed
  - F/B/R with 50% Reverse Speed
- 4. Press and hold the power button for three seconds to save the selection and power OFF.

#### Drag Brake/Max Brake Setting

When the Running Mode set to F/R, drag brake is enabled with the default setting at 1 (0% drag brake). When the Running Mode is set to F/R/B, normal braking is enabled with the default setting at 100% braking force.

- 1. Press and hold the power button for six seconds. The LED flashes twice.
- 2. Release the power button. The number of flashes indicates the brake strength.
- 3. Press the power button to move to the next option.
  - Level 1 is minimum brake strength, level 5 is maximum brake strength.
  - Drag Brake Options (0%, 25%, 50%, 75%, 100%) default level 1, 0%
  - Max Brake Options (60%, 70%, 80%, 90%, 100%) default level 5, 100%
- 4. Press and hold the power button for three seconds to save the selection and power OFF.

#### Low Voltage Cutoff (LVC)

There are three LVC settings, each with a corresponding voltage protection threshold.

When the battery voltage reaches protection mode, the LED flashes slowly and motor speed is limited. When the battery voltage reaches LVC, the LED flashes slowly and the motor powers OFF.

- 1. Press and hold the power button for nine seconds. The LED flashes three times.
- 2. Release the power button. The number of flashes indicates the LVC selection.
- 3. Press the power button to move to the next option.
  - 6.2V LVC (6.4V protection mode): Longer run time but quicker battery degradation.
  - 6.4V LVC (6.6V protection mode): Default, best balance of battery health and run time.
  - 6.6V LVC (6.8V protection mode): Least workload on the battery, shorter run times.
- 4. Press and hold the power button for three seconds to save the selection and power OFF.

AUTO SHUT-OFF: The ESC powers OFF after 10 minutes of transmitter inactivity.

#### **OVERHEAT PROTECTION**


If the ESC overheats, the LED flashes rapidly, and the motor powers OFF.

When the ESC cools, the LED returns to normal, and the motor output returns to normal.


MOTOR TONE			
Two Short Tones 2S Li-Po			
One Long Tone	Receiver is ready to function		

LED		
ON Transmitter and receiver are connected and working properly.		
Short ON / Long OFF Transmitter is not connected to the receiver.		
Slow Flash Low battery voltage		
Quick Flash During Power Up Receiver is in bind mode.		
Quick Flash During Use Overheat protection mode		

## **RECEIVER AND ESC WIRING DIAGRAM**



SPECIFICATIONS			
Voltage Range	6.0-8.4V		
Operating Frequency	2.4GHz		
Continuous/Peak Current	2.5A/5A		
BEC Output	1.5A continuous/2A peak, 6V		
Size	40 x 7 x 14mm		



## **PARTS LIST**

AXI-3066	65T 030-Size Brushed Motor
AXI-3285	88T 030-Size Brushed Motor
AXI-3307	Link Set, Servo Horn
AXI-3308	Chassis
AXI-3311	Transmission, Assembled
AXI-3314	Battery Strap (3)
AXI-3316	Ball Stud Set
AXI-3318	3 x 6 x 2mm, Ball Bearing, Sealed (12)
AXI-3320	Rear Axle, Assembled
AXI-3321	Driveshafts, Front/Rear
AXI-3323	Battery Tray, Universal Mounts & Braces
AXI-3324	Front Axle, Assembled
AXI-3326	O-Ring Set
AXI-3327	Kingpin Screws
AXI-3328	Wheel Nut (8), Wheel Nut Tool
AXI-3331	Screw Set
AXI-3332	Motor Mount Screw (4)
SPMRSLT270	SLT2 2CH 2.4GHz Transmitter
SPMX-1122	7.4V 160mAh 2S 30C Li-Po Battery: PH2.0
SPMXSE3225RX	SCX30 SLT Brushed 2-in-1 ESC/Receiver
SPMSSX112	SCX30 Servo
SPMXC0030	USB 2S Charger: 0.5A JST-XH 3P

### **TROUBLESHOOTING**

PROBLEM	POSSIBLE CAUSE	SOLUTION	
	Batteries are not installed properly in the transmitter	Ensure the transmitter batteries are properly installed	
	Weak or no battery in the vehicle	Install a freshly charged vehicle battery	
Vehicle does not move	Damaged motor	Replace the motor	
IIIOVC	Frayed or broken wiring	Replace any damaged wiring	
	ESC is shut down by heat protection circuit	Allow the ESC to cool down completely	
	Improper antenna placement	Ensure the transmitter antenna is not blocked and the receiver antenna is located properly	
Loss of vehicle control	Weak or no batteries in the transmitter or vehicle	Install a freshly charged vehicle battery and new transmitter batteries	
	Neutral or trim position is incorrect	Adjust the steering trim	
	Receiver and/or battery not connected properly	Check all receiver and battery connections	
Steering and/or throttle function is reversed	Servo travel is reversed at the transmitter	Set the transmitter servo reversing switch to the correct position	
	Motor wires are not connected properly	Check all motor wires for correct polarity and secure connection	

### LIMITED WARRANTY

WHAT THIS WARRANTY COVERS—Horizon Hobby, LLC, (Horizon) warrants to the original purchaser that the product purchased (the "Product") will be free from defects in materials and workmanship for a period of 2 years from the date of purchase.

WHAT IS NOT COVERED—This warranty is not transferable and does not cover (i) cosmetic damage, (ii) damage due to acts of God, accident, misuse, abuse, negligence, commercial use, or due to improper use, installation, operation or maintenance, (iii) modification of or to any part of the Product, (iv) attempted service by anyone other than a Horizon Hobby authorized service center, (v) Product not purchased from an authorized Horizon dealer, or (vi) Product not compliant with applicable technical regulations or (vii) use that violates any applicable laws, rules, or regulations.

OTHER THAN THE EXPRESS WARRANTY ABOVE, HORIZON MAKES NO OTHER WARRANTY OR REPRESENTATION, AND HEREBY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE PURCHASER ACKNOWLEDGES THAT THEY ALONE HAVE DETERMINED THAT THE PRODUCT WILL SUITABLY MEET THE REQUIREMENTS OF THE PURCHASER'S INTENDED USE.

PURCHASER'S REMEDY—Horizon's sole obligation and purchaser's sole and exclusive remedy shall be that Horizon will, at its option, either (i) service, or (ii) replace, any Product determined by Horizon to be defective. Horizon reserves the right to inspect any and all Product(s) involved in a warranty claim. Service or replacement decisions are at the sole discretion of Horizon. Proof of purchase is required for all warranty claims. SERVICE OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY.

LIMITATION OF LIABILITY-HORIZON SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY. REGARDLESS OF WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, TORT, NEGLIGENCE. STRICT LIABILITY OR ANY OTHER THEORY OF LI-ABILITY, EVEN IF HORIZON HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Further, in no event shall the liability of Horizon exceed the individual price of the Product on which liability is asserted. As Horizon has no control over use, setup, final assembly, modification or misuse, no liability shall be assumed nor accepted for any resulting damage or injury. By the act of use, setup or assembly, the user accepts all resulting liability. If you as the purchaser or user are not prepared to accept the liability associated with the use of the Product, purchaser is advised to return the Product immediately in new and unused condition to the place of purchase.

**LAW**—These terms are governed by Illinois law (without regard to conflict of law principals). This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Horizon reserves the right to change or modify this warranty at any time without notice.

#### **WARRANTY SERVICES**

QUESTIONS, ASSISTANCE, AND SERVICES—Your local hobby store and/or place of purchase cannot provide warranty support or service. Once assembly, setup or use of the Product has been started, you must contact your local distributor or Horizon directly. This will enable Horizon to better answer your questions and service you in the event that you may need any assistance. For questions or assistance, please visit our website at www.horizonhobby.com, submit a Product Support Inquiry, or call the toll free telephone number referenced in the Warranty and Service Contact Information section to speak with a Product Support representative.

INSPECTION OR SERVICES—If this Product needs to be inspected or serviced and is compliant in the country you live and use the Product in, please use the Horizon Online Service Request submission process found on our website or call Horizon to obtain a Return Merchandise Authorization (RMA) number. Pack the Product securely using a shipping carton. Please note that original boxes may be included, but are not designed to withstand the rigors of shipping without additional protection. Ship via a carrier that provides tracking and insurance for lost or damaged parcels, as Horizon is not responsible for merchandise until it arrives and is accepted at our facility. An Online Service Request is available at http://www.horizonhobby.com/content/service-center\_render-servicecenter. If you do not have internet access, please contact Horizon Product Support to obtain a RMA number along with instructions for submitting your product for service. When calling Horizon, you will be asked to provide your complete name, street address, email address and phone number where you can be reached during business hours. When sending product into Horizon, please include your RMA number, a

list of the included items, and a brief summary of the problem. A copy of your original sales receipt must be included for warranty consideration. Be sure your name, address, and RMA number are clearly written on the outside of the shipping carton.

**NOTICE:** Do not ship Li-Po batteries to Horizon. If you have any issue with a Li-Po battery, please contact the appropriate Horizon Product Support office.

WARRANTY REQUIREMENTS—For Warranty consideration, you must include your original sales receipt verifying the proof-of-purchase date. Provided warranty conditions have been met, your Product will be serviced or replaced free of charge. Service or replacement decisions are at the sole discretion of Horizon.

NON-WARRANTY SERVICE-Should your service not be covered by warranty, service will be completed and payment will be required without notification or estimate of the expense unless the expense exceeds 50% of the retail purchase cost. By submitting the item for service you are agreeing to payment of the service without notification. Service estimates are available upon request. You must include this request with your item submitted for service. Non-warranty service estimates will be billed a minimum of 1/2 hour of labor. In addition you will be billed for return freight. Horizon accepts money orders and cashier's checks, as well as Visa, MasterCard, American Express, and Discover cards. By submitting any item to Horizon for service, you are agreeing to Horizon's Terms and Conditions found on our website http:// www.horizonhobby.com/content/service-center\_render-service-center.

ATTENTION: Horizon service is limited to Product compliant in the country of use and ownership. If received, a non-compliant Product will not be serviced. Further, the sender will be responsible for arranging return shipment of the un-serviced Product, through a carrier of the sender's choice and at the sender's expense. Horizon will hold non-compliant Product for a period of 60 days from notification, after which it will be discarded.

10/15

## **WARRANTY AND SERVICE CONTACT INFORMATION**

COUNTRY OF PURCHASE	HORIZON HOBBY	CONTACT INFORMATION	ADDRESS	
	Horizon Service Center (Repairs and Repair Requests)	servicecenter.horizonhobby.com/ RequestForm/	2904 Research Rd Champaign, IL 61822	
United States of America	Horizon Product Support (Product Technical Assistance)	productsupport@horizonhobby.com		
		877-504-0233		
	Sales	websales@horizonhobby.com	01022	
		800-338-4639		
European Union	Horizon Technischer Service	service@horizonhobby.eu	Hanskampring 9 D 22885	
	Sales: Horizon Hobby GmbH	+49 (0) 4121 2655 100	Barsbüttel, Germany	

### **FCC INFORMATION**

#### FCC ID: BRWSPMSLT200F

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm

between the radiator and/or antenna and your body (excluding fingers, hands, wrists, ankles and feet). This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### SUPPLIER'S DECLARATION OF CONFORMITY Axial SCX30 1/30th Scale 4WD RTR

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television

Horizon Hobby, LLC 2904 Research Road, Champaign, IL 61822 Email: compliance@horizonhobby.com Web: HorizonHobby.com

## **IC INFORMATION**

#### IC: 6157A-SPMSLT200F CAN ICES-3 (B)/NMB-3(B)

This device contains license-exempt transmitter(s)/receivers(s) that comply with Innovation, Science, and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following 2 conditions:

- This device may not cause interference.
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

## **COMPLIANCE INFORMATION FOR THE EUROPEAN UNION**

EU Compliance Statement: Axial SCX30 1/30th Scale 4WD RTR: Hereby, Horizon Hobby, LLC declares that the device is in compliance with the following: EU Low Voltage Directive 2014/35/EU: EU EMC Directive 2014/30/EU; EU Radio Equipment Directive 2014/53/EU: RoHS 2 Directive 2011/65/ EU; RoHS 3 Directive - Amending 2011/65/EU Annex II 2015/863.

The full text of the EU declaration of conformity is available at the following internet address: https:// www.horizonhobby.com/content/support-rendercompliance.

**NOTE:** This product contains batteries that are covered under the 2006/66/EC European Directive. which cannot be disposed of with normal household waste. Please follow local regulations.

Wireless Frequency Range and Wireless Output Power Transmitter: 2410MHz-2480MHz 13.66 dBm



### **EU Manufacturer of Record:**

Horizon Hobby, LLC 2904 Research Road Champaign, IL 61822 USA

#### **EU Importer of Record:**

Horizon Hobby, GmbH Hanskampring 9 22885 Barsbüttel Germany

#### WEEE NOTICE:

This appliance is labeled in accordance with European Directive 2012/19/EU concerning waste of electrical and electronic equipment (WEEE). This label

indicates that this product should not be disposed of with household waste. It should be deposited at an appropriate facility to enable recovery and recyclina.

## EXPLODED VIEWS // EXPLOSIONSZEICHNUNGEN // VUES ÉCLATÉES // VISTE ESPLOSE

#### **AXI-3311**

Transmission (assembled) Getriebe( montiert) Transmission (assemblée) Trasmissione (assemblata)

**AXI-3318** 

Bearing Set Lagersatz

Ensemble de roulement

Set cuscinetti

AXI-3331

Screw Set Schraubensatz

Ensemble de vis


Set viti

030er Bürstenmotor, separat erhältlich Moteur à balais taille 030, vendu séparément Motore a spazzole 030, venduto separatamente

M1.4 x 12

AXI-3326

030-Size Brushed Motor, sold separately






#### **AXI-3321**


Driveshafts, Front/Rear Antriebswellen Front/Heck Arbres de transmission avant/arrière Alberi trasmissione ant./post.



## EXPLODED VIEWS // EXPLOSIONSZEICHNUNGEN // VUES ÉCLATÉES // VISTE ESPLOSE



#### AXI-3320





## EXPLODED VIEWS // EXPLOSIONSZEICHNUNGEN // VUES ÉCLATÉES // VISTE ESPLOSE

# AXI-3307 Links Set, Servo Horn Verbindungssatz, Servohorn Ensemble de tringleries, renvoi de commande du servo M1 x 6 Set leveraggi, squadretta servo AXI-3316 **Ball Stud Set** M1 x 8 Kugelzapfensatz Ensemble piton à rotule Set bulloni a sfera M1 x 8 M1 x 6 M1 x 8 AXI-3328 **6** AXI-3328




## EXPLODED VIEWS // EXPLOSIONSZEICHNUNGEN // VUES ÉCLATÉES // VISTE ESPLOSE

#### AXI-3308

Chassis Fahrwerk

Châssis Telaio











## EXPLORE

FACEBOOK.COM/AXIALINC
INSTAGRAM.COM/AXIALADVENTURE
TWITTER.COM/AXIALRC
YOUTUBE.COM/AXIALVIDEOS

